

Pigmofix RF

8103

Additive for solvent-based 2-component PU furniture coatings for professional and industrial use

PRODUCT DESCRIPTION

Product numbers

90695

General

Additive for solvent-based pigmented two-component PU coatings to achieve very good ring resistance and to increase mar resistance.

Application area



As an additive to Pigmopur G50 (2406) for the final coating application to increase ring resistance and scratch resistance.

Please refer to the corresponding technical data sheets of the products.

PROCESSING

Processing instructions



- Please stir the product before use.
- **Carefully stir the product into the coating until free of lumps.**
- Pigmofix RF (8103) does not affect the drying of Pigmopur G50 (2406). Excellent ring resistance is achieved after 1 to 2 days.
- For repair coating, thoroughly clean the area to be repaired with DD-Verdünner 8519 (8519) and carefully sand it.
- Pigmofix RF (8103) does not affect the gloss level of the resulting surface.
- Any change in the processing sequence, environmental conditions, non-observance of instructions or the use of products not listed may have an unfavourable effect on the result.
- Please follow our **ARL 131 - Working guidelines for PUR furniture paints.**

Quantity to be added



10% on coating (excluding hardener and thinner quantities)

Cleaning the working equipment



8519



8501

With DD-Verdünner 8519 (8519) or Waschverdünner (8501) immediately after use.

ORDERING INFORMATION

Size of trading unit 400 g

FURTHER DETAILS

Durability / storage

Min. 1 year(s) in the original sealed containers.

Make sure the product is protected against moisture, direct sunlight, frost and high temperatures (above 30 °C).

Close opened containers well and use up the content as soon as possible.

Safety information

The product is only suitable for the industrial and professional use.

Further information on the subject of safety during transport, storage and handling as well as disposal can be found in the relevant safety data sheet. The current version can be accessed on the Internet at **www.adler-lacke.com**.
